
Ultrasound-Assisted Lumbar Puncture

Highland General Hospital Division of Emergency Ultrasound


Step I

- -Curvilinear transducer pointing cephalad
- -Slide transducer just off midline
- -Visualize articular processes or "humps"




Step 2

- -Slide transducer caudal until the sacrum is visualized
- -Note the L/5/S1, L4/L5 and L3/L4 interspaces



Step 3

-Mark the L3/L4 and L4/L5 interspace



Step 4

- -Rotate probe marker to patient's left
- -Locate bony midline

